















Original		Replacement		Original		Replacement	
	Power		Power		>>		>> / Tune+
	Mute		Mute / Dimmer		Menu		Menu / Home
	Red		Red / Netflix / Search		Up		Up
	Green		Green / APP / Repeat		Back		Back / Return
	Yellow		Yellow / YouTube / Repeat		Left		Left
	Blue		Blue / Prime Video / Random		OK		OK
	Internet		Smart / List		Right		Right
	Source		AV / Input / RDS		i		Info / Angle
	Lang		Audio / Lang I/II		Down		Down
	Tv/Radio		TV/Radio /		Exit		Exit / Cancel / Clear
	Subtitle		Subtitle / EQ		Vol+		Vol+
	LIB		Picture / Format		P::P		Display / Media
	Rec		Rec / Rec Mode		PR+		CH+ / Page+
	Stop		Stop / Hold		Vol-		Vol-
	<<		<< / Tune-		FAV		Fav / Marker / PC
	Play		Play / Slow		PR-		CH- / Page-
	Pause		Pause / Step / Freeze		1		1





Original		Replacement		Original		Replacement	
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	Text		Text / Goto				
	0		0				
	Guide		Guide / EPG / -/--				

