
















Original	Replacement	Original	Replacement
 AV/Input	 AV / Input / RDS	 Return	 Back / Return
 Power	 Power	 Rec	 Rec / Rec Mode
 Open/Close	 Eject / Surround	 Marker	 Fav / Marker / PC
 DVD	 Shift + 2	 Stop	 Stop / Hold
 HDD	 Shift + 7	 Play	 Play / Slow
 Audio	 Audio / Lang I/II	 Pause/Step	 Pause / Step / Freeze
 Title	 Sound / Title	 I<< Skip	 I<< / Preset-
 Display	 Display / Media	 << Scan	 << / Tune-
 Home	 Shift + Menu /	 Scan >>	 >> / Tune+
 Menu/List	 Menu / Home	 >>I Skip	 >>I / Preset+
 Up	 Up	 Red/FAV	 Red / Netflix / Search
 PR/CH+	 CH+ / Page+	 Green/Repeat	 Green / APP / Repeat
 Left	 Left	 Yellow/Subtitle	 Yellow / YouTube / Repeat
 Enter	 OK	 Blue	 Blue / Prime Video / Random
 Right	 Right	 Text	 Text / Goto
 Down	 Down	 EPG	 Guide / EPG / -/-
 PR/CH-	 CH- / Page-	 Timeshift	 Sleep / Timer



