







































































Original	Replacement	Original	Replacement
	Power		Power
	Eject		Eject
	USB		Media
	Radio		TV/R
	Aux/Di/MP3 Link		AV
	HDMI		Pre Ch
	Disc		Menu
	Info		Info
	Back/Title		Back
	Options		Options
	Up		Up
	Down		Down
	Right/>>>		Right
	Left/;<<		Left
	OK		Ok
	I<		I<<
	Play		Play
	Pause		Pause
	>		>>
	Stop		Stop
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Treble		Ch +
	Bass		Ch -
	Ambisound		Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8





Original		Replacement		Original		Replacement	
	9		9				
	0		0				
	Subtitle		Subt				
	Audio Sync		Format				
	Zoom		Shift + Eject				
	Angle		Sleep				
	Repeat/Program		Text				
	Sound		Dual				

