






















































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	Function		Menu
	Sound		Dual
	EQ		Subt
	DVD		Media
	1/Timer On/Off		1
	2/Timer/Clock		2
	3/Sleep		3
	4/Disc Menu		4
	5/Title Menu		5
	6		6
	7		7
	8/SYNC		8
	9		9
	0		0
	Vol+		Vol +
	Vol-		Vol -
	I<<</RDS PTY		I<<<
	>>>I		>>>I
	<<<		<<<
	>>>/RDS Display		>>>
	Stop		Stop
	Play		Play
	Pause		Pause
	Repeat		Text
	Home		Smart
	USB Rec		Rec
	Tools		Options
	Info		Info
	Return		Back
	Exit		Exit
	Up/Tuning Up		Up
	Down/Tuning		Down



Down



Original	Replacement	Original	Replacement
 Right/#	 Right		
 Left/b	 Left		
 Enter	 Ok		
 Red/Display	 Red		
 GreenMo/ST	 Green		
 Yellow	 Yellow		
 Blue/Keycon	 Blue		
 Speed/CD Rec	 3D		
 My Karaoke	 TV/R		
 Mic Vol+	 Ch +		
 Mic Vol-	 Ch -		

