













	Original	Replacement		Original	Replacement
	Power		Power		>>I
	Source		AV		<<
	Open/Close		Eject		>>
	Sleep		Sleep		Stop
	1		1		Play
	2		2		Pause
	3		3		Vol +
	4		4		Vol -
	5		5		Mute
	6		6		Repeat
	7		7		Tuning+
	8		8		Tuning-
	9		9		Disc Menu
	0		0		Menu
	Dolby PL		Dual		Title Menu
	DSP/EQ		Guide		Tools
	I<<		I<<		Info





Original		Replacement		Original		Replacement	
	Return		Back				
	Exit		Exit				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	Enter		Ok				
	Red		Red				
	Green/Tuner		Green				
	Yellow/MO/ST		Yellow				
	Blue/CD Ripping		Blue				
	Dimmer		Subt				
	S.Vol		Format				
	P.Bass/Audio Upscale		3D				





Original	Replacement	Original	Replacement
 Power	 Power	 Pause	 Pause
 Function Tv	 AV	 Vol+	 Vol +
 Sleep	 Sleep	 Vol-	 Vol -
 1	 1	 Mute	 Mute
 2	 2	 CH+	 Ch +
 3	 3	 CH-	 Ch -
 4	 4	 Menu	 Menu
 5	 5	 Tools	 Options
 6	 6	 Info	 Info
 7	 7	 Return	 Back
 8	 8	 Exit	 Exit
 9	 9	 Up	 Up
 0	 0	 Down	 Down
 <<	 <<	 Right	 Right
 >>	 >>	 Left	 Left
 Stop	 Stop	 Enter	 Ok
 Play	 Play	 Red	 Red





Original	Replacement	Original	Replacement
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

