






































Original	Replacement
 Power	 Power
 DTV / ATV	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 - / +	 Shift + Guide
 Recall	 Back
 P.Mode	 Shift + Format
 S.Mode	 Dual
 Aspect	 Format

Original	Replacement
 Still	 Pause
 P -	 Ch -
 P +	 Ch +
 V -	 Vol -
 V +	 Vol +
 Sleep	 Sleep
 Mute	 Mute
 MTS	 Shift + Media
 Menu	 Menu
 Source	 AV
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 Enter	 Ok
 Exit	 Exit
 i	 Info





Original	Replacement	Original	Replacement
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text / <<		Text
	Text / <<<		<<<
	Hold / >>>		>>>
	Hold / >>		Shift + Pause
	Mix / I<<<		I<<<
	Mix / I<<		Shift + Text
	Timer / >>>I		>>>I
	[≡] / Play/Pause		Play
	[≡] / Play/Pause		Shift + Info
	Size / Stop		Stop
	Size / Stop		Eject
	[?]		D. Menu
	Subtitle		Subt

