





































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PR.List	 List
 Recall	 Back
 Vol +	 Vol +
 Vol -	 Vol -
 Pic. Mode	 Options

Original	Replacement
 S. Mode	 Dual
 Source	 AV
 Prog +	 Ch +
 Prog -	 Ch -
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Exit	 Exit
 Menu	 Menu
 Zoom	 Eject
 Sleep	 Sleep
 DNR	 Shift + Options
 MTS	 Format
 Red	 Red
 Green	 Green





Original		Replacement		Original		Replacement	
	Yellow		Yellow				
	Blue		Blue				
	FAV		Pre Ch				
	TV / Radio		TV/R				
	Audio		Shift + Dual				
	Subtitle		Subt				
	Size		3D				
	Reveal		D. Menu				
	EPG		Guide				
	Info		Info				
	Text		Text				
	Index		Shift + Info				
	Subpage		Shift + Subt				
	Hold		Stop				

