











Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Media	 Display / Media
 Portal	 Shift + Menu /
 Help	 Shift + Info / Angle
 Menu	 Menu / Home
 Up	 Up

Original	Replacement
 Exit	 Exit / Cancel / Clear
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Guide	 Guide / EPG / -/--
 i	 Info / Angle
 Vol +	 Vol+
 Back	 Back / Return
 CH +	 CH+ / Page+
 Vol -	 Vol-
 Filelist	 Smart / List
 CH -	 CH- / Page-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random





Original	Replacement
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Rec	 Rec / Rec Mode
 I<<	 I<< / Preset-
 <<	 << / Tune-
 >>	 >> / Tune+
 >>I	 >>I / Preset+
 TV / Radio	 TV/Radio /
 Audio	 Audio / Lang I/II
 Subt	 Subtitle / EQ
 TTX	 Text / Goto
 Timer	 Shift + Sleep / Timer
 Sleep	 Sleep / Timer

Original	Replacement

