




































































Original	Replacement	Original	Replacement
 Power	 Power	 Vol+	 Vol +
 Sleep	 Sleep	 Vol-	 Vol -
 CBL/Sat	 1	 Mute	 Mute
 Media Player	 2	 Info	 Info
 Blu-ray/DVD	 3	 Option	 Options
 Game	 4	 Back	 Back
 AUX	 5	 Setup	 Menu
 Tuner	 6	 Up	 Up
 iPod/USB	 7	 Down	 Down
 Tv Audio	 8	 Right	 Right
 CD	 9	 Left	 Left
 Online Music	 Guide	 Enter	 Ok
 Bluetooth	 0	 I<</Tune-	 I<<
 Internet Radio	 Pre Ch	 Play	 Play
 CH/Page+	 Ch +	 Pause	 Pause
 CH/Page-	 Ch -	 >>I/Tune+	 >>I
 Eco	 3D	 Smart Select 1	 D. Menu



