







































































Original		Replacement		Original		Replacement	
	Standby		Power		Down		Down
	Mute		Mute		Right		Right
	P/N		Smart		Left		Left
	Open/Close		Eject		OK		Ok
	<<		<<		Vol+		Vol +
	>>		>>		Vol-		Vol -
	Play/Pause		Play		1		1
	Stop		Stop		2		2
	I<<		I<<		3		3
	>>I		>>I		4		4
	Setup		Options		5		5
	Source		AV		6		6
	Info		Info		7		7
	Return/Exit		Exit		8		8
	CH+		Ch +		9		9
	CH-		Ch -		0		0
	Up		Up		Slow		Back





Original	Replacement	Original	Replacement
GOTO	MEDIA		
PROGRAM	SLEEP		
TITLE/TTX	TEXT		
AUDIO	DUAL		
SUBTITLE	SUBT		
REPEAT	A		
A-B	B		
MENU	C		
ANGLE	D		
EPG	GUIDE		
FAVORITE	PRE-CH		
TV/RADIO	TV/R		
ZOOM	SHIFT + ZOOM		

