



































































Original	Replacement
 TV	 Shift + 1
 AV.SV	 AV / Input / RDS
 SCART1	 Shift + 3
 PC	 Shift + Fav / Marker / PC
 SCART2	 Shift + 2
 Mute	 Mute / Dimmer
 Up / P+	 Up
 Up / P+	 CH+ / Page+
 Exit	 Exit / Cancel / Clear
 Left / Vol-	 Left
 Left / Vol-	 Vol-
 Menu / Enter	 OK
 Menu / Enter	 Menu / Home
 Right / Vol+	 Right
 Right / Vol+	 Vol+
 Down / P-	 Down
 Down / P-	 CH- / Page-

Original	Replacement
 Text	 Text / Goto
 Red	 Red / Netflix / Search
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Green	 Green / APP / Repeat
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 +100	 Guide / EPG / -/-
 0	 0
 RTN	 Back / Return





Original		Replacement	
	RTN		Fav / Marker / PC
	Sound		Sound / Title
	PIP Source Up		Shift + Up
	Display		Display / Media
	PIP Position		Shift + Left
	PIP On/Off		Shift + OK
	PIP Size		Shift + Right
	APC		D.Menu / Top
	PIP Source		Shift + Down
	ARC		Setup / OPT /
	[]		Stop / Hold
	[≡i]		Play / Slow
	[↓]		>> / Tune+
	[≡?]		Pause / Step / Freeze
	[⊖]		<< / Preset-
	[≡X]		<< / Tune-
	Sleep		Sleep / Timer

Original		Replacement	
	Reset		Smart / List
	Power		Power

