











































Original		Replacement	
	Power		Power
	Input		Source
	APA		Mode
	Eco Mode		Eco / Aspect
	Menu		Menu
	Reset	 + 	Shift + Power
	Up		Up
	Left		Left
	Enter		Enter
	Right		Right
	Down		Down
	Return		Auto
	Aspect	 + 	Shift + Eco / Aspect
	Keystone	 + 	Shift + Down
	Keystone	 + 	Shift + Up
	Pattern		Comp / Video
	D Zoom+		+ / Play

Original		Replacement	
	D Zoom-		- / Stop
	Vol+		Vol + / Page +
	Vol-		Vol - / Page -
	Freeze		Freeze / Timer
	Blank		Blank / Mute
	Muting	 + 	Shift + Blank / Mute

