







































































| Original  | Replacement | Original  | Replacement           |
|---|-------------|---|-----------------------|
|      | Power       |      | Power                 |
|      | Mute        |      | Mute / Dimmer         |
|      | 1           |      | 1                     |
|      | 2           |      | 2                     |
|      | 3           |      | 3                     |
|      | 4           |      | 4                     |
|      | 5           |      | 5                     |
|      | 6           |      | 6                     |
|      | 7           |      | 7                     |
|     | 8           |     | 8                     |
|    | 9           |    | 9                     |
|    | DTV/ATV     |    | Info / Angle          |
|    | 0           |    | 0                     |
|    | Recall      |    | Back / Return         |
|    | P.Mode      |    | Picture / Format      |
|    | S.Mode      |    | Sound / Title         |
|    | Sleep       |    | Sleep / Timer         |
|    | Vol+        |    | Vol+                  |
|    | MTS         |    | Setup / OPT /         |
|    | CH+         |    | CH+ / Page+           |
|    | Vol-        |    | Vol-                  |
|    | RecList     |    | Smart / List          |
|    | CH-         |    | CH- / Page-           |
|    | FAV/List    |    | Fav / Marker / PC     |
|    | Rec         |    | Rec / Rec Mode        |
|    | Freeze      |    | Pause / Step / Freeze |
|   | Menu        |   | Menu / Home           |
|  | Up          |  | Up                    |
|  | Source      |  | AV / Input / RDS      |
|  | Left        |  | Left                  |
|  | Enter       |  | OK                    |
|  | Right       |  | Right                 |
|  | Exit        |  | Exit / Cancel / Clear |
|  | Down        |  | Down                  |



