







































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	Tv/Sat		TV/R
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	FAV		Pre Ch
	Sub		Subt
	Menu		Menu
	EPG		Guide
	TXT		Text
	Exit		Exit
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+ / USB		Vol +
	Vol- / USB Game-		Vol -
	CH/Page+		Ch +
	CH/Page-		Ch -
	Red/SAT		Red
	Green/Zoom		Green
	Green/Zoom		Eject
	Yellow/EPG+		Yellow
	Yellow/EPG+		Shift + Guide
	Blue/Tv/Radio		Blue





Original		Replacement		Original	Replacement
	Info		Info		
	Audio		Dual		
	M-P		Smart		
	RCL		Media		
	<<		<<		
	>>		>>		
	I<<		I<<		
	>>I		>>I		
	Play		Play		
	Rec		Rec		
	Stop		Stop		
	Slow		Shift + Play		
	Pause		Pause		

