




































Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 Options	Menu Off	 Exit
Txt Stop	 Stop	Menu Down	 Down
Reveal	 List	Back	 Back
Info	 +  Shift + Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7



Original	Replacement	Original	Replacement
8	 8	Output	 Shift + Vol -
9	 9	Nicam/Mono	 Shift + Green
Guide -/-- 1.	 Guide	Color- S.Std	 Shift + Dual
0/10	 0	Level L	 Shift + Yellow
2.Fav P/C 2.	 Pre Ch	Level R/Woofer	 Shift + Blue
Red	 Red		
Green	 Green		
Yellow	 Yellow		
Blue	 Blue		
Tone-	 <<		
Tone+	 >>		
Audio-	 I<<		
Audio+	 >>I		
Color+ P.Std	 Shift + D. Menu		
AV 2	 Shift + AV		
Browse	 Shift + Back		
Input	 Shift + Vol +		

