


















































































Original	Replacement	Original	Replacement
 Power	 Power	 Dev.List	 Display / Media
 Mute	 Mute / Dimmer	 EPG	 Guide / EPG / -/-
 1	 1	 Subtitle	 Subtitle / EQ
 2	 2	 Text	 Text / Goto
 3	 3	 Auto	 Setup / OPT /
 Lang	 Audio / Lang I/II	 Menu	 Menu / Home
 4	 4	 Zoom	 Zoom / Size
 5	 5	 Info	 Info / Angle
 6	 6	 Exit	 Exit / Cancel / Clear
 Game	 Picture / Format	 Up	 Up
 7	 7	 CH+	 CH+ / Page+
 8	 8	 Left	 Left
 9	 9	 Vol-	 Vol-
 Tv/Radio	 TV/Radio /	 Enter	 OK
 FAV	 Fav / Marker / PC	 Right	 Right
 0	 0	 Vol+	 Vol+
 Recall	 Back / Return	 CH-	 CH- / Page-

Original	Replacement	Original	Replacement
 Power	 Mute / Dimmer	 Shift	
 TV	 DVD	 SAT	 AUX
 SLOW	 STEP-FREEZE	 HOLD	 REC MODE
 TUNE-	 TUNE+	 PRESET-	 PRESET+
 TITLE	 LANG I/II	 EQ	 SURROUND
 SOUND	 AUDIO	 SUBTITLE	 PROGRAM
 FORMAT	 ZOOM	 SLEEP	 TV RADIO
 PICTURE	 OPT-TOOLS	 GOTO	 RDS
 TOP MENU	 OPT-TOOLS	 GOTO	 AV INPUT
 D.MENU	 SETUP	 TEXT	
 HOME	 ANGLE	 INFO	
 MENU	 OK	 RETURN	
 CLEAR	 EXIT	 BACK	
 CANCEL	 LIST	 SMART	
 VOL +	 MEDIA	 CH PAGE	
 VOL -	 DISPLAY		
 TV	 DVD	 CD - STB	
 1	 TAPE	 TUNER	
 4	 USB	 BLUETOOTH	
 AUX - HDD	 HDMI - BAT	 PC	
 7	 GUIDE EPG	 0	 FAV MARKER
 NETFLIX	 APP	 YouTube	 Prime Video
 SEARCH	 REPEAT	 REPEAT A-B	 RANDOM





	Original	Replacement	Original	Replacement
		Down		Down
		Filelist		Smart / List
		Rec		Rec / Rec Mode
		Stop		Stop / Hold
		Play		Play / Slow
		Pause		Pause / Step / Freeze
		<<		<< / Tune-
		>>		>> / Tune+
		I<<		I<< / Preset-
		>>I		>>I / Preset+
		Red/FAV./Daily		Red / Netflix / Search
		Green/Del./Weekl		Green / APP / Repeat
		Yellow/Move/P.Inf		Yellow / YouTube / Repeat
		Blue/Look/Timer		Blue / Prime Video / Random

