







































































Original	Replacement	Original	Replacement
 Power	 Power	 Pause	 Pause
 Mute	 MUTE	 Play	 Play
 Screen	 WIDE	 Stop	 Stop
 Tv / AV	 SRC	 Rec	 Rec
 1	 1	 Up	 UP
 2	 2	 Down	 DOWN
 3	 3	 Right	 RIGHT
 4	 4	 Left	 LEFT
 5	 5	 CH+	 CH +
 6	 6	 CH-	 CH -
 7	 7	 Vol+	 VOL +
 8	 8	 Vol-	 VOL -
 9	 9	 OK	 OK
 0	 0	 Tv-Menu	 MENU
 -/--	 -/-- / EPG	 Exit	 EXIT
 Return	 BACK	 Info	 INFO
 Open / Close	 VOD	 Subtitle	 Subt.



