





































Original		Replacement		Original		Replacement	
	Power		Power		Text		Text
	Mute		Mute		FAV		Pre Ch
	TV/SAT		AV		P-		Ch -
	SAT		Smart		P+		Ch +
	TV		Media		Info		Info
	Radio		TV/R		Up		Up
	Recall		Back		Left		Left
	1		1		OK		Ok
	2		2		OK		Shift + Ok
	3		3		Right		Right
	4		4		Down		Down
	5		5		Menu		Menu
	6		6		Exit		Exit
	7		7		Red / Lang		Red
	8		8		Red / Lang		Dual
	9		9		Green / Pause		Green
	0		0		Green / Pause		Pause



