



| Original | Replacement | Original | Replacement |
|---|--------------|---|----------------|
|  | Power |  | Power |
|  | Mute |  | Mute |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | -/-- |  | Guide |
|  | Recall |  | Back |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Nicam |  | Dual |
|  | Sleep |  | Sleep |
|  | Display |  | Info |
|  | CH+ |  | Ch + |
|  | CH- |  | Ch - |
|  | Up |  | Up |
|  | Left |  | Left |
|  | OK |  | Ok |
|  | Right |  | Right |
|  | Down |  | Down |
|  | Aspect |  | Format |
|  | Source |  | AV |
|  | P.Mode |  | Shift + Format |
|  | S.Mode |  | Shift + Dual |
|  | Exit |  | Exit |
|  | Menu |  | Menu |
|  | Media |  | Media |
|  | Play / Pause |  | Play |



