







Original		Replacement		Original		Replacement	
	Power		Power		CH/Page Down		Ch -
	Sleep		Sleep		Vol+		Vol +
	CBL/SAT		1		Vol-		Vol -
	DVD		2		Mute		Mute
	Blu-ray		3		Info		Info
	Game		4		Option		Options
	AUX		5		Back		Back
	Media Player		6		Setup		Menu
	Phono		7		Up		Up
	TV Audio		8		Down		Down
	Tuner		9		Right		Right
	USB		Guide		Left		Left
	Bluetooth		0		Enter		Ok
	Internet Radio		Pre Ch		I<</Tune-		I<<
	Eco		Media		Play		Play
	Eco		3D		Pause		Pause
	CH/Page Up		Ch +		>>I/Tune+		>>I









Original	Replacement	Original	Replacement
 Power	 Power	 Vol+	 Vol +
 Sleep	 Sleep	 Vol-	 Vol -
 CBL/SAT	 1	 Mute	 Mute
 DVD	 2	 Back	 Back
 Blu-ray	 3	 Up	 Up
 Game	 4	 Down	 Down
 AUX	 5	 Right	 Right
 Media Player	 6	 Left	 Left
 Phono	 7	 Enter	 Ok
 TV Audio	 8	 I<</Tune-	 I<<
 Tuner	 9	 Play	 Play
 USB	 Guide	 Pause	 Pause
 Bluetooth	 0	 >>I/Tune+	 >>I
 Internet Radio	 Pre Ch	 Quick Select 1	 D. Menu
 :I:	 Media	 Quick Select 2	 Text
 CH/Page Up	 Ch +	 Quick Select 3	 Eject
 CH/Page Down	 Ch -	 Quick Select 4	 AV

