




























































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute / Dimmer
	V.Format		Shift + Picture / Format
	Sleep		Sleep / Timer
	Text		Text / Goto
	TV / Radio		TV/Radio /
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	[[≡]]		Smart / List
	0		0
	Recall		Back / Return
	Vol -		Vol-
	Vol +		Vol+
	CH -		CH- / Page-
	CH +		CH+ / Page+
	Menu		Menu / Home
	Up		Up
	Exit		Exit / Cancel / Clear
	Left		Left
	OK		OK
	Right		Right
	Page Down		Shift + CH- /
	Down		Down
	Page Up		Shift + CH+ /
	FAV		Fav / Marker / PC
	Guide		Guide / EPG / -/-
	Info		Info / Angle





Original	Replacement
	 Display / Media
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Audio / Lang I/II
	 Blue / Prime Video / Random
	 Subtitle / EQ
	 Play / Slow
	 Stop / Hold
	 Pause / Step / Freeze
	 Rec / Rec Mode
	 Shift + Text /
	 Shift + Pause / Step /
	 << / Tune-
	 >> / Tune+
	 Zoom / Size
	 Shift + Stop /

Hold

Original	Replacement
	 I<< / Preset-
	 >>I / Preset+
	 Shift + 0
	 Picture / Format
	 Setup / OPT /
	 Shift + Setup / OPT / Tools

