







































































Original		Replacement		Original		Replacement	
	Power		Power		Right		Right
	Mute		Mute / Dimmer		Exit		Exit / Cancel / Clear
	Play		Play / Slow		Down		Down
	Pause		Pause / Step / Freeze		←		Back / Return
	Stop		Stop / Hold		V+		Vol+
	Rec		Rec / Rec Mode		Smart		Smart / List
	<<		<< / Tune-		P+		CH+ / Page+
	>>		>> / Tune+		V-		Vol-
	Lang		Audio / Lang I/II		P-		CH- / Page-
	[≡]..		Subtitle / EQ		1		1
	Text		Text / Goto		2		2
	Source		AV / Input / RDS		3		3
	Menu		Menu / Home		4		4
	Up		Up		5		5
	i		Info / Angle		6		6
	Left		Left		7		7
	OK		OK		8		8



