







































































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 DTV/ATV	 Info
 Recall	 Pre Ch
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 Sleep	 Sleep

Original	Replacement
 Menu	 Menu
 Source	 AV
 Enter	 Ok
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Exit	 Exit
 Display	 Shift + Info
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 MTS	 Shift + Sleep
 Rec List	 D. Menu
 FAV/List	 Dual
 Rec	 Rec





Original	Replacement	Original	Replacement
Freeze	Options		
<</Guide	<<		
>>/Aspect	>>		
I<</Cancel	+ Shift + Subt		
>>I/Sub.Pg	Back		
Stop/Index	Stop		
Play/Pause/Time Shift	Play		
Tv/Radio	TV/R		
Subtitle	Subt		
Reveal	+ Shift + Options		
Size	Format		
Hold	Eject		
Text	Text		
Red	Red		
Green	Green		
Yellow	Yellow		
Cyan	Blue		

Original	Replacement

