







































































Original		Replacement		Original		Replacement	
	Power		Power		Vol-		Vol -
	Source		AV		P+		Ch +
	1		1		P-		Ch -
	2		2		Menu		Menu
	3		3		Q.Menu		D. Menu
	4		4		Back		Back
	5		5		Exit		Exit
	6		6		OK		Ok
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	TV		TV/R		i/Info		Info
	Recall		Pre Ch		Music/Photo/Phot		Options
	Mute		Mute		Guide		Guide
	Internet		Smart		[≡]/Text		Text
	Vol+		Vol +		*/O		Format





Original	Replacement	Original	Replacement
*/Q	3D		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		
Lang	Dual		
[≡]..	Subt		
Rec	Rec		
[-o-]	Eject		
Play	Play		
Stop	Stop		
Pause	Pause		
<<	<<		
>>	>>		

