












































































































Original		Replacement		Original		Replacement	
	Standby/On		Power		Memo/Mark		Pre Ch
	Tv/Video		TV/R		PR/CH+		Ch +
	Output Select		AV		PR/CH-		Ch -
	DV		Green		F1		Shift + 1
	HDD		Yellow		F2		Shift + 2
	DVD		Blue		Edit		Guide
	1		1		Prog		Sleep
	2		2		Top Menu		Shift + Menu
	3		3		Navigation		List
	4		4		Menu		Menu
	5		5		Return		Back
	6		6		Up		Up
	7		7		Down		Down
	8		8		Right		Right
	9		9		Left		Left
	0		0		Enter		Ok
	Cancel		Exit		I<<		I<<





Original		Replacement		Original		Replacement	
	>>I		>>I		Progressive Scan		Text
	<</Slow-		<<		Set Up		Options
	Play		Play				
	>>/Slow+		>>				
	Rec		Rec				
	Stop/Clear		Stop				
	Pause		Pause				
	Display		Info				
	On Screen		3D				
	←		Media				
	→		Smart				
	Rec		Format				
	Audio		Dual				
	Subtitle		Subt				
	Angle/EE Check		Red				
	EE		Eject				
	Dubbing		D. Menu				





Original		Replacement		Original		Replacement	
	Standby/On		Power		PR/CH-		Ch -
	Tv/Video		TV/R		Input Select		AV
	Mute		Mute		F1		Smart
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Cancel		Back				
	Vol+		Vol +				
	Vol-		Vol -				
	PR/CH+		Ch +				

