





































Original	Replacement
 Power	 Shift + Power
 AMP Power	 Power
 Tuner Preset ▼	 CH- / Page-
 Tuner Preset ▲	 CH+ / Page+
 Tuner	 Shift + 6
 CD	 Shift + 3
 Recorder	 Rec / Rec Mode
 Network	 Shift + 4
 Phono	 Shift + 5
 Coaxial	 D.Menu / Top
 Optical	 Shift + 7
 I<<	 I<< / Preset-
 Sound Mode	 Sound / Title
 >>I	 >>I / Preset+
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze

Original	Replacement
 Input	 AV / Input / RDS
 Info	 Info / Angle
 Source Direct	 Smart / List
 Mute	 Mute / Dimmer
 Volume+	 Vol+
 Volume-	 Vol-
 Time/Home	 Display / Media
 Mode	 Picture / Format
 Prog/Favorite	 Fav / Marker / PC
 Menu	 Menu / Home
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Enter	 OK
 1	 1
 2	 2















Original	Replacement
	
	
	
	
	
	
	
	
	 Guide / EPG / -/--
	 Exit / Cancel / Clear
	 +  Shift + Mute / Dimmer
	 Blue / Prime Video / Random
	 Green / APP / Repeat
	 Zoom / Size

Original	Replacement





Original	Replacement
 Power	 Shift + Power
 AMP Power	 Power
 Tuner	 Shift + 6
 Tuner Preset ▼	 CH - / Page-
 Tuner Preset ▲	 CH+ / Page+
 CD	 Shift + 3
 Recorder	 Shift + 8
 Network	 Shift + 4
 Phono	 Shift + 5
 Coaxial	 Shift + 9
 Optical	 Shift + 7
 I<<	 I<< / Preset-
 Sound Mode	 Sound / Title
 >>I	 >>I / Preset+
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze

Original	Replacement
 Input	 Display / Media
 Source Direct	 AV / Input / RDS
 Volume+	 Vol+
 Info	 Info / Angle
 Mute	 Mute / Dimmer
 Volume-	 Vol-
 Time/Home	 Sleep / Timer
 Mode	 Picture / Format
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Prog/Favorite	 Fav / Marker / PC
 Down	 Down
 Menu	 Menu / Home
 1	 1
 2	 2



