







































































Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV/Source		AV
	-/--		Shift + Guide
	[i]/Info		Info
	CH+		Ch +
	CH-		Ch -
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	[≡i]/Guide		Guide
	Menu		Menu
	Red		Red
	Exit		Exit
	Green		Green
	I-II		Dual
	Swap/P<P		Pre Ch
	Yellow		Yellow
	TV/DTV		TV/R
	<<		I<<





	Original	Replacement	Original	Replacement
	Blue	 D		Blue
	<<			<<
	Play			Play
	>>			>>
	>>>			>>>
	Stop			Stop
	Pause/[+]			Pause
	Rec/PP			Rec
	[≡+]			Options
	[≡x]			Subt
	[.≡]			Media
	[≡]			Text
	[≡?]			Format
	[≡o]			3D

