





















Original		Replacement		Original		Replacement	
	Power		Power		V-		Vol -
	Source		AV		P+		Ch +
	1		1		P-		Ch -
	2		2		[G]		Guide
	3		3		i		Info
	4		4		Back		Back
	5		5		Exit		Exit
	6		6		OK		Ok
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	TXT		Text		Netflix		Media
	Lang		Dual		YouTube		Smart
	Mute		Mute		Prime Video		Shift + Smart
	Home		Menu		*1		Format
	V+		Vol +		Red		Red





	Original	Replacement		Original	Replacement
			Green		
			Yellow		
			Blue		
			<<		
			Pause		
			>>		
			Rec		
			Play		
			Stop		

