






































Original	Replacement
 Power	 Power
 Tv	 TV/Radio /
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Enter	 OK
 PRE-CH	 Back / Return
 CH LIST	 Shift + Smart / List
 FAV CH	 Fav / Marker / PC
 Tools	 Setup / OPT /

Original	Replacement
 Menu	 Menu / Home
 Return	 Shift + Back / Return
 Info	 Info / Angle
 Internet	 Smart / List
 Exit	 Exit / Cancel / Clear
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red / Netflix / Search
 Enter	 Shift + OK
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer





	Original	Replacement	Original	Replacement
	Source	 AV / Input / RDS		
	PR+	 CH+ / Page+		
	PR-	 CH- / Page-		
	TTX/MIX	 Text / Goto		
	Media.P	 Display / Media		
	Content	 Picture / Format		
	Guide	 Guide / EPG / -/--		
	Subt	 Subtitle / EQ		
	<<	 << / Tune-		
	Pause	 Pause / Step / Freeze		
	>>	 >> / Tune+		
	Rec	 Rec / Rec Mode		
	Play	 Play / Slow		
	Stop	 Stop / Hold		

