







































































Original		Replacement		Original		Replacement	
	Standby		Power		Down		Down
	Rec PVR		Rec		Right		Right
	List PVR		Smart		Left		Left
	Mute		Mute		OK		Ok
	EPG		Guide		Vol+		Vol +
	Audio		Dual		Vol-		Vol -
	Info		Info		1		1
	DTV/VCR		Media		2		2
	TTX		Text		3		3
	Subtitle		Subt		4		4
	Menu		Menu		5		5
	Exit		Exit		6		6
	Favourite		Pre Ch		7		7
	Tv/Radio		TV/R		8		8
	CH+		Ch +		9		9
	CH-		Ch -		0		0
	Up		Up		Recall		Back

























































Original		Replacement		Original		Replacement	
	Goto		AV				
	<<		<<				
	>>		>>				
	I<<		I<<				
	>>I		>>I				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Repeat	 + 	Shift + Text				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				





	Original	Replacement		Original	Replacement
	Standby		Power		Down
	Rec PVR		Rec		Right
	List PVR		List		Left
	Mute		Mute		Ok
	EPG		Guide		Vol +
	Audio		Dual		Vol -
	Info		Info		1
	DTV/VCR		Media		2
	TTX		Text		3
	Subtitle		Subt		4
	Menu		Menu		5
	Exit		Exit		6
	Favourite		Pre Ch		7
	Tv/Radio		TV/R		8
	CH+		Ch +		9
	CH-		Ch -		0
	Up		Up		Recall
					Back





Original	Replacement	Original	Replacement
GOTO	Options		
<<	<<		
>>	>>		
I<<	I<<		
>>I	>>I		
Play	Play		
Pause	Pause		
Stop	Stop		
Repeat	+ Shift + Text		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		

