







































































Original		Replacement		Original		Replacement	
	Power		Power		7		7
	Sleep		Sleep / Timer		Dimmer		Shift + Mute / Dimmer
	Input TV		AV / Input / RDS		8		8
	Power TV		Shift + Power		Time		Shift + Sleep / Timer
	Program		TV/Radio /		9		9
	1		1		0		0
	2		2		0/Subtitle		Subtitle / EQ
	Repeat		Green / APP / Repeat		Audio		Audio / Lang I/II
	Function+		CH+ / Page+		Angle		Info / Angle
	3		3		DVD Top Menu		Menu / Home
	EQ		Shift + Subtitle / EQ		DVD Menu		D.Menu / Top
	4		4		Setup		Setup / OPT /
	DSGX		Sound / Title		Display		Display / Media
	5		5		Muting		Mute / Dimmer
	Function-		CH- / Page-		Vol+		Vol+
	6		6		Vol-		Vol-
	Zoom		Zoom / Size		Up		Up



