














Original	Replacement
 Standby	 Power
 Open/Close	 Eject / Surround
 OSD	 Display / Media
 1	 1
 2	 2
 3	 3
 Prog	 TV/Radio /
 4	 4
 5	 5
 6	 6
 A-B	 Yellow / YouTube / Repeat
 7	 7
 8	 8
 9	 9
 Repeat	 Green / APP / Repeat
 Goto	 Text / Goto
 0/10	 0

Original	Replacement
 10+	 Guide / EPG / -/-
 L/R/ST/Mo	 Sound / Title
 P/N	 Blue / Prime Video / Random
 Audio	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 Stop/Mem	 Stop / Hold
 I<</Station-	 I<< / Preset-
 >>I/Station+	 >>I / Preset+
 Play/Pause/FM/AM	 Play / Slow
 Slow	 Shift + Play /
 <</Search-	 << / Tune-
 >>/Search+	 >> / Tune+
 Step	 Pause / Step / Freeze
 Menu	 Menu / Home
 Return	 Back / Return
 Angle	 Info / Angle
 Up	 Up



