



Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	-/--		Guide / EPG / -/--
	0		0
	Recall		Back / Return
	Vol+		Vol+
	Disp		Display / Media
	CH+		CH+ / Page+
	Vol-		Vol-
	Input		AV / Input / RDS
	CH-		CH- / Page-
	Zoom		Zoom / Size
	Up		Up
	Sleep		Sleep / Timer
	Left		Left
	Enter		OK
	Right		Right
	Down		Down
	Exit		Exit / Cancel / Clear
	Menu		Menu / Home
	P.Mode		Picture / Format
	S.Mode		Sound / Title
	Auto		Smart / List
	Angle		Info / Angle
	I<<		I<< / Preset-



