
























































Original	Replacement	Original	Replacement
 Power	 Power	 Vol+	 Vol +
 AUDIO	 Red	 Vol-	 Vol -
 CD	 Green	 Auto	 Subt
 AUX	 Yellow	 DSP -	 Shift + Left
 TV	 Blue	 DSP +	 Shift + Right
 VCR	 Shift + Red	 Stereo	 Dual
 DVD	 Shift + Green	 Setup / OSD	 Options
 CABLE	 Shift + Yellow	 Menu / T.Tone	 Menu
 SAT	 Shift + Blue	 Up	 Up
 CH Sel	 TV/R	 Left	 Left
 CH/Level Up	 Ch +	 Enter	 Ok
 CH/Level Down	 Ch -	 Right	 Right
 SPK SET	 Exit	 Down	 Down
 PLII PARA.	 D. Menu	 Display / Sleep	 Info
 Adjust -	 Shift + Down	 Display / Sleep	 Sleep
 Adjust +	 Shift + Up	 Return /	 Back
 Mute	 Mute	 Stop / P.Scan	 Stop





Original	Replacement	Original	Replacement
 << / Tune -	 <<	 AUX Pause	 Shift + Pause
 >> / Tune +	 >>	 AUX Play	 Shift + Play
 I<< / Preset -	 I<<	 AUX Stop	 Shift + Stop
 >>I / Preset +	 >>I	 AUX <<	 Shift + <<
 7CH Dir	 ECO 3D	 AUX >>	 Shift + >>
 1 / Tuner	 1	 AUX >>I	 Shift + >>I
 2 / CD	 2	 AUX I<<	 Shift + I<<
 3 / AUX	 3		
 4 / Tape	 4		
 5	 5		
 6 / Video 1	 6		
 7 / Video 2	 7		
 8 / Video 3	 8		
 9	 9		
 0	 0		
 AUX Power /	 Shift + Power		
 AUX Rec	 Shift + Rec		





Original	Replacement	Original	Replacement
 AUDIO	 Red	 TV 3	 3
 CD	 Green	 TV 4	 4
 AUX	 Yellow	 TV 5	 5
 TV	 Blue	 TV 6	 6
 VCR	 Shift + Red	 TV 7	 7
 DVD	 Shift + Green	 TV 8	 8
 CABLE	 Shift + Yellow	 TV 9	 9
 SAT	 Shift + Blue	 TV 0	 0
 TV Power	 Power	 CABLE Power	 Shift + Power
 TV CH +	 Ch +	 CABLE CH/Level +	 Shift + Ch +
 TV CH -	 Ch -	 CABLE CH/Level -	 Shift + Ch -
 TV CH Sel.	 Media	 CABLE CH Sel.	 Shift + Smart
 TV Mute	 Mute	 CABLE Mute	 Shift + Mute
 TV Volume +	 Vol +	 CABLE Volume	 Shift + Vol +
 TV Volume -	 Vol -	 CABLE Volume -	 Shift + Vol -
 TV 1	 1	 CABLE 1	 Shift + 1
 TV 2	 2	 CABLE 2	 Shift + 2









































































Original	Replacement	Original	Replacement
CABLE 3	SHIFT + 3 Shift + 3		
CABLE 4	SHIFT + 4 Shift + 4		
CABLE 5	SHIFT + 5 Shift + 5		
CABLE 6	SHIFT + 6 Shift + 6		
CABLE 7	SHIFT + 7 Shift + 7		
CABLE 8	SHIFT + 8 Shift + 8		
CABLE 9	SHIFT + 9 Shift + 9		
CABLE 0	SHIFT + 0 Shift + 0		





Original	Replacement	Original	Replacement
 AUDIO	 Red	 DVD Right	 Right
 CD	 Green	 DVD Down	 Down
 AUX	 Yellow	 DVD Display	 Info
 TV	 Blue	 DVD Pause	 Pause
 VCR	 Shift + Red	 DVD Play	 Play
 DVD	 Shift + Green	 DVD Stop	 Stop
 SAT	 Shift + Blue	 DVD <<	 <<
 CABLE	 Shift + Yellow	 DVD >>	 >>
 DVD Power	 Power	 DVD I<<	 I<<
 DVD Menu	 Menu	 DVD >>I	 >>I
 DVD Audio Sel.	 Dual	 DVD 1	 1
 DVD Subtitle	 Subt	 DVD 2	 2
 DVD Zoom	 3D	 DVD 3	 3
 DVD OSD /	 Format	 DVD 4	 4
 DVD Up	 Up	 DVD 5	 5
 DVD Left	 Left	 DVD 6	 6
 DVD Enter	 Ok	 DVD 7	 7






































































	Original	Replacement	
	DVD 8		8
	DVD 9		9
	DVD 0		0
	SAT Power	+	Shift + Power
	SAT CH +	+	Shift + Ch +
	SAT CH -	+	Shift + Ch -
	SAT CH Sel.	+	Shift + Media
	SAT Mute	+	Shift + Mute
	SAT Volume +	+	Shift + Vol +
	SAT Volume -	+	Shift + Vol -
	SAT 1	+	Shift + 1
	SAT 2	+	Shift + 2
	SAT 3	+	Shift + 3
	SAT 4	+	Shift + 4
	SAT 5	+	Shift + 5
	SAT 6	+	Shift + 6
	SAT 7	+	Shift + 7

	Original	Replacement	
	SAT 8	+	Shift + 8
	SAT 9	+	Shift + 9
	SAT 0	+	Shift + 0





Original	Replacement	Original	Replacement
	 Red		 5
	 Green		 6
	 Yellow		 7
	 Blue		 8
	 +  Shift + Red		 9
	 +  Shift + Blue		 0
	 +  Shift + Yellow		 +  Shift + Power
	 +  Shift + Green		 +  Shift + Media
	 Pause		 +  Shift + Rec
	 Play		 +  Shift + Play
	 Stop		 +  Shift + Mute
	 I<<		 +  Shift + >>
	 >>I		 +  Shift + <<
	 1		 +  Shift + Vol -
	 2		 +  Shift + Vol +
	 3		 +  Shift + Ch +
	 4		 +  Shift + Ch -





	Original	Replacement	
	VCR Pause	SHIFT +	Shift + Pause
	VCR Stop	SHIFT +	Shift + Stop
	VCR 1	SHIFT +	Shift + 1
	VCR 2	SHIFT +	Shift + 2
	VCR 3	SHIFT +	Shift + 3
	VCR 4	SHIFT +	Shift + 4
	VCR 5	SHIFT +	Shift + 5
	VCR 6	SHIFT +	Shift + 6
	VCR 7	SHIFT +	Shift + 7
	VCR 8	SHIFT +	Shift + 8
	VCR 9	SHIFT +	Shift + 9
	VCR 0	SHIFT +	Shift + 0

Original	Replacement

