Original		Replacement	
POWER	Power		Power
TV/RAD	TV/RAD	PROGRAM TV/RADIO	TV/Radio /
INPUT	Input	RDS AV INPUT	AV / Input / RDS
AV MODE	AV Mode	FORMAT PICTURE	Picture / Format
ENERGY SAVING	Energy Saving	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
Q.VIEW	Q.View	MEDIA DISPLAY	Display / Media

Original		Replacement	
	Vol +	VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
P	PR+/Page Up	CH PAGE	CH+ / Page+
	Vol -	VOL	Vol -
P	PR-/Page Down	CH PAGE	CH- / Page-
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
RETURN/EXIT	Return	RETURN BACK	Back / Return
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green/Stop	APP REPEAT	Green / APP / Repeat
	Green/Stop	HOLD	Stop / Hold
	Yellow/Play	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Yellow/Play	SLOW	Play / Slow

Original		Replacement		Original		Replacement	
	Blue/Pause		Blue / Prime Video / Random				
	Blue/Pause		Pause / Step / Freeze				
TEXT	Text/[≡]	GOTO TEXT	Text / Goto				
T.OPT	T.OPT/<<	PRESET-	I<< / Preset-				
T.OPT	T.OPT/<<	OPT-TOOLS SETUP	Setup / OPT /				
T.OPT	T.OPT/<<	TUNE-	<< / Tune-				
SUBTITLE	Subtitle/>>	PRESET+	>>I / Preset+				
SUBTITLE	Subtitle/>>	EQ SUBTITLE	Subtitle / EQ				
SUBTITLE	Subtitle/>>	TUNE+	>> / Tune+				
SIMPLINK	Simplink	TIMER SLEEP	Sleep / Timer				
Q.MENU	Q.Menu	TOP MENU D.MENU	D.Menu / Top				
INFO	Info	ANGLE INFO	Info / Angle				
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--				
MARK FAV	FAV/Mark	PC FAV MARKER	Fav / Marker / PC				