Original		Replacement	
POWER	Power		Power
CD/ TAPE	CD/ Tape	MEDIA DISPLAY	Display / Media
CD/ TAPE	CD/ Tape	SHIFT + TAPE 5	Shift + 5
CD/ TAPE	CD/ Tape	SHIFT + CD-STB 3	Shift + 3
TUNER/ BAND	Tuner/ Band	LIST SMART	Smart / List
TUNER/ BAND	Tuner/ Band	SHIFT + TUNER 6	Shift + 6
DECK 1/2 1	1/ Deck 1/ 2	TV 1	1
2	2/ <<	DVD 2	2
2	2/ <<		Down
3	3/ >>	CD-STB 3	3
3	3/ >>		Up
4	4/ < Tape	VIDEO 4	4
4	4/ < Tape		Left
5	5/ Stop Tape	TAPE 5	5
5	5/ Stop Tape	OK	OK
6	6/ Tape >	TUNER 6	6
6	6/ Tape >		Right

Original		Replacement	
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
≥10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
PROGRAM	Program	PROGRAM TV/ RADIO	TV/ Radio /
CD	Play CD	SLOW	Play / Slow
CD	Stop CD	HOLD	Stop / Hold
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TUNE-	I <</ <<	TUNE-	<< / Tune-
PRESET-	I <</ <<	PRESET-	I << / Preset-
TUNE+	>>/ >>I	TUNE+	>> / Tune+
PRESET+	>>/ >>I	PRESET+	>>I / Preset+
EQ SPACE	EQ Space	EQ SUBTITLE	Subtitle / EQ
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
VOL-	Vol -	VOL -	Vol -

Original	Replacement	Original	Replacement
Vol +	Vol +		