| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power TV | Power | Up TV | Up |
| Mute TV TV | Mute / Dimmer | Left/RDS TV | Left |
| Play/Save TV | Play / Slow | OK TV | OK |
| Pause TV | Pause / Step / Freeze | Right/PTY TV | Right |
| Stop TV | Stop / Hold | Clear TV | Exit / Cancel / Clear |
| Rec TV | Rec / Rec Mode | Down TV | Down |
| <</Tuner- TV | << / Tune- | Back/ST-Mono | Back / Return |
| >>/Tuner+ TV | >> / Tune+ | Vol + TV TV | Vol + |
| PR-/I<< TV | I<< / Preset- | PR+/>>I TV | CH+ / Page+ |
| PR+/>>I TV | >>I / Preset+ | Vol - TV TV | Vol - |
| Level TV | Sound / Title | PR-/I<< TV | CH- / Page- |
| Subwoofer TV | Audio / Lang I/II | 1 Tv | 1 |
| Equalizer TV | Subtitle / EQ | 2 TV | 2 |
| Surround TV | Eject / Surround | 3 TV | 3 |
| Night TV | Sleep / Timer | 4 TV | 4 |
| Setup TV | Setup / OPT / | 5 TV | 5 |
| Menu TV TV | Menu / Home | 6 TV | 6 |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 7 TV | 7 | Up AUX1 | Shift + Up |
| 8 TV | 8 | Left / RDS AUX1 | Shift + Left |
| 9 TV | 9 | OK AUX1 | Shift + OK |
| Guide TV | Guide / EPG / -/-- | Right / PTY AUX1 | Shift + Right |
| 0 TV | 0 | Down AUX1 | Shift + Down |
| Tape-CD | Red / Netflix / Search | PR+/ >>I AUX1 | Shift + CH+ / |
| AUX1 (VCR) | Green / APP / Repeat | PR- / I <<AUX1 | Shift + CH- / |
| Aux2 (SAT-Cable | Yellow / YouTube / Repeat | 1 AUX1 | Shift + 1 |
| Power AUX1 | Shift + Power | 2 AUX1 | Shift + 2 |
| Play/Save AUX1 | Shift + Play / | 3 AUX1 | Shift + 3 |
| Pause AUX1 | Shift + Pause / Step / | 4 AUX1 | Shift + 4 |
| Stop AUX1 | Shift + Stop / | 5 AUX1 | Shift + 5 |
| Rec AUX1 | Shift + Rec / Rec Mode | 6 AUX1 | Shift + 6 |
| <</Tuner- | Shift + << / | 7 AUX1 | Shift + 7 |
| >>/Tuner+ | Shift + >> / | 8 AUX1 | Shift + 8 |
| PR- / I <<AUX1 | Shift + I<< / Preset- | 9 AUX1 | Shift + 9 |
| PR+/ >>I AUX1 | Shift + >>I / Preset+ | Guide AUX1 | Shift + Guide / EPG / -/-- |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 0 AUX1 | SHIFT + HDMI - SAT 0 | Shift + 0 | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power DVD6CH | Power | Up DVD6CH | Up |
| Mute DVD6CH | Mute / Dimmer | Left/RDS | Left |
| Play/Save | Play / Slow | OK DVD6CH | OK |
| Pause DVD6CH | Pause / Step / Freeze | Right/PTY | Right |
| Stop DVD6CH | Stop / Hold | Clear DVD6CH | Exit / Cancel / Clear |
| Rec DVD6CH | Rec / Rec Mode | Down DVD6CH | Down |
| <</Tuner- | << / Tune- | Back/St-Mono | Back / Return |
| >>/Tuner+ | >> / Tune+ | Vol + DVD6CH | Vol + |
| PR-/I<< | I<< / Preset- | PR+/>>I | CH+ / Page+ |
| PR+/>>I | >>I / Preset+ | Vol - DVD6CH | Vol - |
| Level DVD6CH | Sound / Title | PR-/I<< | CH- / Page- |
| Subwoofer | Audio / Lang I/II | 1 DVD6CH | 1 |
| Equalizer | Subtitle / EQ | 2 DVD6CH | 2 |
| Surround | Eject / Surround | 3 DVD6CH | 3 |
| Night DVD6CH | Sleep / Timer | 4 DVD6CH | 4 |
| Setup DVD6CH | Setup / OPT / | 5 DVD6CH | 5 |
| Menu DVD6CH | Menu / Home | 6 DVD6CH | 6 |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 7 DVD6CH | 7 | Up Tape-CD | Shift + Up |
| 8 DVD6CH | 8 | Left/RDS Tape-CD | Shift + Left |
| 9 DVD6CH | 9 | OK Tape-CD | Shift + OK |
| Guide DVD6CH | Guide / EPG / -/-- | Right/PTY | Shift + Right |
| 0 DVD6CH | 0 | Down Tape-CD | Shift + Down |
| Tape-CD | Red / Netflix / Search | Back/ST-Mono Tape-CD | Shift + Back / Return |
| AUX1 (VCR) | Green / APP / Repeat | PR+/ >>I | Shift + CH+ / |
| Aux2 (SAT-Cable | Yellow / YouTube / Repeat | PR-/ I << | Shift + CH- / |
| Power Tape-CD | Shift + Power | 1 Tape-CD | Shift + 1 |
| Play/Save | Shift + Play / | 2 Tape-CD | Shift + 2 |
| Pause Tape-CD | Shift + Pause / Step / | 3 Tape-CD | Shift + 3 |
| Stop Tape-CD | Shift + Stop / | 4 Tape-CD | Shift + 4 |
| Rec Tape-CD | Shift + Rec / Rec Mode | 5 Tape-CD | Shift + 5 |
| <</Tuner- | Shift + << / | 6 Tape-CD | Shift + 6 |
| >>/Tuner + | Shift + >> / | 7 Tape-CD | Shift + 7 |
| PR-/ I << | Shift + I << / Preset- | 8 Tape-CD | Shift + 8 |
| PR+/ >>I | Shift + >>I / Preset+ | 9 Tape-CD | Shift + 9 |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 0 Tape-CD | SHIFT + HDMI-SAT 0 | Shift + 0 | |

| Original | Replacement |
|---|---|
| Power TUNER | Power |
| Mute TUNER | Mute / Dimmer |
| Play/Save | Play / Slow |
| Pause TUNER | Pause / Step / Freeze |
| Stop TUNER | Stop / Hold |
| <</Tuner- | << / Tune- |
| >>/Tuner+ | >> / Tune+ |
| PR-/I<< TUNER | I<< / Preset- |
| PR+/>>I TUNER | >>I / Preset+ |
| Level TUNER | Sound / Title |
| Subwoofer | Audio / Lang I/II |
| Equalizer | Subtitle / EQ |
| Surround | Eject / Surround |
| Night TUNER | Sleep / Timer |
| Setup TUNER | Setup / OPT / |
| Menu TUNER | Menu / Home |
| Up TUNER | Up |

| Original | Replacement |
|---|---|
| Left/RDS TUNER | Left |
| OK TUNER | OK |
| Right/PTY | Right |
| Clear TUNER | Exit / Cancel / Clear |
| Down TUNER | Down |
| Back/St-Mono | Back / Return |
| Vol + TUNER | Vol + |
| PR+/>>I TUNER | CH+ / Page+ |
| Vol - TUNER | Vol - |
| PR-/I<< TUNER | CH- / Page- |
| 1 TUNER | 1 |
| 2 TUNER | 2 |
| 3 TUNER | 3 |
| 4 TUNER | 4 |
| 5 TUNER | 5 |
| 6 TUNER | 6 |
| 7 TUNER | 7 |

| Original | Replacement |
|---|---|
| 8 TUNER | 8 |
| 9 TUNER | 9 |
| Guide TUNER | Guide / EPG / -/-- |
| 0 TUNER | 0 |
| Tape-CD | Red / Netflix / Search |
| AUX1 (VCR) | Green / APP / Repeat |
| Aux2 (SAT- Cable | Yellow / YouTube / Repeat |
| Power AUX2 | Shift + Power |
| Play/Save AUX2 | Shift + Play / |
| Pause AUX2 | Shift + Pause / Step / |
| Stop AUX2 | Shift + Stop / |
| Rec AUX2 | Shift + Rec / Rec Mode |
| <</Tuner- | Shift + << / |
| >>/Tuner+ | Shift + >> / |
| PR-/I<< AUX2 | Shift + I<< / Preset- |
| PR+/>>I AUX2 | Shift + >>I / Preset+ |
| Menu AUX2 | Shift + Menu / Home |

| Original | Replacement |
|---|---|
| Up AUX2 | Shift + Up |
| Left/RDS AUX2 | Shift + Left |
| OK AUX2 | Shift + OK |
| Right/PTY AUX2 | Shift + Right |
| Clear AUX2 | Shift + Exit / Cancel / Clear |
| Down AUX2 | Shift + Down |
| Back/St-Mono | Shift + Back / Return |
| PR+/>>I AUX2 | Shift + CH+ / |
| PR-/I<< AUX2 | Shift + CH- / |
| 1 AUX2 | Shift + 1 |
| 2 AUX2 | Shift + 2 |
| 3 AUX2 | Shift + 3 |
| 4 AUX2 | Shift + 4 |
| 5 AUX2 | Shift + 5 |
| 6 AUX2 | Shift + 6 |
| 7 AUX2 | Shift + 7 |
| 8 AUX2 | Shift + 8 |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 9 AUX2 | SHIFT + 9 | | |
| Guide AUX2 | SHIFT + GUIDE EPG | | |
| 0 AUX2 | SHIFT + 0 | | |