Original		Replacement	
ON/STANDBY	On / Standby		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
BD/DVD	Input BD/DVD	SHIFT + DVD 2	Shift + 2
VCR/DVR	Input VCR/DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	Input CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	Input Game	SHIFT + TAPE 5	Shift + 5
AUX	Input AUX	SHIFT + AUX - HDD 7	Shift + 7
TUNER	Input Tuner	SHIFT + TUNER 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + TV 1	Shift + 1
TV/CD	Input TV/CD	SHIFT + CD - STB 3	Shift + 3
PORT	Input Port	SHIFT + USB 8	Shift + 8
TUN MODE	Tun Mode	LIST SMART	Smart / List
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
+	Tone +	SHIFT + TUNE+	Shift + >> /
CH +	CH +	CH PAGE +	CH+ / Page+
VOL +	Vol +	VOL +	Vol +
−	Tone	GOTO TEXT	Text / Goto

Original		Replacement	
−	Tone -	SHIFT + TUNE-	Shift + << /
CH −	CH -	CH PAGE −	CH- / Page-
VOL −	Vol -	VOL −	Vol -
GUIDE/TOP MENU SP A/B	Guide / Top Menu	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
GUIDE/TOP MENU SP A/B	Guide / Top Menu	TOP MENU D.MENU	D.Menu / Top
	Up		Up
PREV CH/MENU	Prev CH / Menu	HOME MENU	Menu / Home
PREV CH/MENU	Prev CH / Menu	PC FAV MARKER	Fav / Marker / PC
PLAYLIST /CATEGORY	Left / Playlist/Category		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right / Playlist/Category		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
⏮	I <<	PRESET- ⏮	I << / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+

Original		Replacement	
◄◄	<<	TUNE- ◄◄	<< / Tune-
►	Play	SLOW ►	Play / Slow
►►	>>	TUNE+ ►►	>> / Tune+
◄II	Pause / Play Reverse	STEP-FREEZE II	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
MOVIE/TV SEARCH	Movie/TV / Searc	NETFLIX SEARCH	Red / Netflix / Search
MOVIE/TV SEARCH	Movie/TV / Searc	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
MUSIC REPEAT	Music / Repeat	APP REPEAT	Green / APP / Repeat
MUSIC REPEAT	Music / Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
GAME RANDOM	Game / Random	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
GAME RANDOM	Game / Random	YouTube REPEAT A-B	Yellow / YouTube / Repeat
STEREO PLAY MODE	Stereo / Play	TITLE SOUND	Sound / Title
STEREO PLAY MODE	Stereo / Play	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4

Original		Replacement	
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
D.TUN +10 DIMMER	+10 / Dimmer	-/-- GUIDE EPG	Guide / EPG / -/--
D.TUN +10 DIMMER	D.Tun Tuner	ANGLE INFO	Info / Angle
D.TUN +10 DIMMER	+10 / Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
0	0	HDMI-BAT 0	0
CLR SLEEP	Clear / Sleep	TIMER SLEEP	Sleep / Timer
CLR SLEEP	Clear / Sleep	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Replacement	
ON/STANDBY	On/Standby		Power
ON/STANDBY	On/Standby	SHIFT +	Shift + Power
DISPLAY	Display BD/DVD	MEDIA DISPLAY	Display / Media
BD/DVD	Input BD/DVD	SHIFT + DVD 2	Shift + 2
VCR/DVR	Input VCR/DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	Input CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	Input Game	SHIFT + TAPE 5	Shift + 5
AUX	Input AUX	SHIFT + AUX - HDD 7	Shift + 7
TUNER	Input Tuner	SHIFT + TUNER 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + TV 1	Shift + 1
TV/CD	Input TV/CD	SHIFT + CD - STB 3	Shift + 3
PORT	Input Port	SHIFT + USB 8	Shift + 8
TONE	Tone	GOTO TEXT	Text / Goto
TUN MODE	Tun Mode	LIST SMART	Smart / List
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
+	Tone +	SHIFT + TUNE+	Shift + >> /
VOL	Vol +	VOL +	Vol +

Original		Replacement	
–	Tone -	SHIFT + TUNE-	Shift + << /
VOL	Vol -	VOL –	Vol -
GUIDE/TOP MENU SP A/B	Guide / Top Menu BD/DVD	TOP MENU D.MENU	D.Menu / Top
GUIDE/TOP MENU SP A/B	Guide / Top Menu BD/DVD	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
	Up BD/DVD		Up
PREV CH/MENU	Prev CH / Menu BD/DVD	PC FAV MARKER	Fav / Marker / PC
PREV CH/MENU	Prev CH / Menu BD/DVD	HOME MENU	Menu / Home
PLAYLIST /CATEGORY	Left / Playlist/Category		Left
ENTER	Enter BD/DVD	OK	OK
PLAYLIST /CATEGORY	Right / Playlist/Category		Right
SETUP	Setup BD/DVD	OPT-TOOLS SETUP	Setup / OPT /
	Down BD/DVD		Down
RETURN	Return BD/DVD	RETURN BACK	Back / Return
AUDIO	Audio BD/DVD	LANG I/II AUDIO	Audio / Lang I/II
	I<< BD/DVD	PRESET-	I<< / Preset-
	>>I BD/DVD	PRESET+	>>I / Preset+
	<< BD/DVD	TUNE-	<< / Tune-

Original		Replacement	
	Play BD/DVD	SLOW	Play / Slow
	>> BD/DVD	TUNE+	>> / Tune+
	Pause BD/DVD	STEP-FREEZE	Pause / Step / Freeze
	Stop BD/DVD	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie/TV / Search BD/DVD	NETFLIX SEARCH	Red / Netflix / Search
MOVIE/TV SEARCH	Movie/TV / Search BD/DVD	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
MUSIC REPEAT	Music / Repeat BD/DVD	APP REPEAT	Green / APP / Repeat
MUSIC REPEAT	Music / Repeat BD/DVD	SHIFT + APP REPEAT	Shift + Green / APP /
GAME RANDOM	Game / Random BD/DVD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
GAME RANDOM	Game / Random BD/DVD	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
STEREO PLAY MODE	Stereo / Play Mode BD/DVD	Prime Video RANDOM	Blue / Prime Video / Random
1	1 BD/DVD	TV 1	1
2	2 BD/DVD	DVD 2	2
3	3 BD/DVD	CD-STB 3	3
4	4 BD/DVD	VIDEO 4	4
5	5 BD/DVD	TAPE 5	5
6	6 BD/DVD	TUNER 6	6

Original		Replacement	
7	7 BD/DVD	AUX-HDD 7	7
8	8 BD/DVD	USB 8	8
9	9 BD/DVD	BLUETOOTH 9	9
+10 D.TUN DIMMER	+10 / Dimmer	-/-- GUIDE EPG	Guide / EPG / -/--
0	0 BD/DVD	HDMI-SAT 0	0
CLR SLEEP	CLR / Sleep	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CLR SLEEP	CLR / Sleep	TIMER SLEEP	Sleep / Timer

Original		Replacement	
On / Standby		Power	
On / Standby		Shift +	Power
Display TV/CD		Display /	Media
Input BD/DVD		Shift +	2
Input VCR/DVR		Shift +	4
Input CBL/SAT		Shift +	0
Input Game		Shift +	5
Input Aux		Shift +	7
Input Tuner		Shift +	6
Input TV/CD		Shift +	1
Input TV/CD		Shift +	3
Input Port		Shift +	8
Tun Mode		Smart /	List
Muting		Mute /	Dimmer
Tone +		Shift +	>> /
Disc + / Album + TV/CD		CH+ /	Page+
Vol +		Vol +	

Original		Replacement	
Tone		Text /	Goto
Tone -		Shift +	<< /
Disc - / Album - TV/CD		CH- /	Page-
Vol -		Vol -	
Up TV/CD		Up	
Left / Playlist/Category		Left	
Enter TV/CD		OK	
Right / Playlist/Category		Right	
Setup TV/CD		Setup /	OPT /
Down TV/CD		Down	
Return TV/CD		Back /	Return
Audio TV/CD		Audio /	Lang I/II
I<< TV/CD		I<< /	Preset-
>>I TV/CD		>>I /	Preset+
<< TV/CD		<< /	Tune-
Play TV/CD		Play /	Slow
>> TV/CD		>> /	Tune+

Original		Replacement	
	Pause TV/CD	STEP-FREEZE	Pause / Step / Freeze
	Stop TV/CD	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	NETFLIX SEARCH	Red / Netflix / Search
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
MUSIC REPEAT	Music / Repeat TV/CD	APP REPEAT	Green / APP / Repeat
MUSIC REPEAT	Music / Repeat TV/CD	SHIFT + APP REPEAT	Shift + Green / APP /
GAME RANDOM	Game / Random	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
GAME RANDOM	Game / Random	YouTube REPEAT A-B	Yellow / YouTube / Repeat
STEREO PLAY MODE	Stereo / Play Mode TV/CD	Prime Video RANDOM	Blue / Prime Video / Random
1	1 TV/CD	TV 1	1
2	2 TV/CD	DVD 2	2
3	3 TV/CD	CD-STB 3	3
4	4 TV/CD	VIDEO 4	4
5	5 TV/CD	TAPE 5	5
6	6 TV/CD	TUNER 6	6
7	7 TV/CD	AUX-HDD 7	7
8	8 TV/CD	USB 8	8

Original		Replacement	
9	9 TV/CD	BLUETOOTH 9	9
+10 D.TUN DIMMER	+10 / Dimmer	-/-- GUIDE EPG	Guide / EPG / -/--
0	0 TV/CD	HDMI-SAT 0	0
CLR SLEEP	CLR / Sleep TV/CD	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CLR SLEEP	CLR / Sleep TV/CD	TIMER SLEEP	Sleep / Timer

Original		Replacement	
On / Standby		Power	
On / Standby Por		SHIFT + Power	Shift +
Display Port		DISPLAY	Display / Media
Input BD/DVD		SHIFT + 2	Shift + 2
Input VCR/DVR		SHIFT + 4	Shift + 4
Input CBL/SAT		SHIFT + 0	Shift + 0
Input Game		SHIFT + 5	Shift + 5
Input AUX		SHIFT + 7	Shift + 7
Input Tuner		SHIFT + 6	Shift + 6
Input TV/CD		SHIFT + 3	Shift + 3
Input TV/CD		SHIFT + 1	Shift + 1
Input Port		SHIFT + 8	Shift + 8
Tone		TEXT	Text / Goto
Tun Mode		SMART	Smart / List
Muting		MUTE	Mute / Dimmer
Tone +		SHIFT + TUNE+	Shift + >> /
CH + Port		CH+	CH+ / Page+

Original		Replacement	
Vol +		VOL +	Vol +
Tone -		SHIFT + TUNE-	Shift + << /
CH - Port		CH-	CH- / Page-
Vol -		VOL -	Vol -
Up Port		Up	
Left / Playlist/Category		Left	
Enter Port		OK	OK
Right / Playlist/Categor		Right	
Setup Port		SETUP	Setup / OPT /
Down Port		Down	
Return Port		BACK	Back / Return
I<< Port		PRESET-	I<< / Preset-
>>I Port		PRESET+	>>I / Preset+
<< Port		TUNE-	<< / Tune-
Play Port		SLOW	Play / Slow
>> Port		TUNE+	>> / Tune+
Pause / Play Reverse Port		STEP-FREEZE	Pause / Step / Freeze

Original		Replacement	
	Stop Port	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie/TV / Search Port	NETFLIX SEARCH	Red / Netflix / Search
MOVIE/TV SEARCH	Movie/TV / Search Port	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
MUSIC REPEAT	Music / Repeat	APP REPEAT	Green / APP / Repeat
MUSIC REPEAT	Music / Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
GAME RANDOM	Game / Random	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
GAME RANDOM	Game / Random	YouTube REPEAT A-B	Yellow / YouTube / Repeat
STEREO PLAY MODE	Stereo / Play Mode Port	Prime Video RANDOM	Blue / Prime Video / Random
1	1 Port	TV 1	1
2	2 Port	DVD 2	2
3	3 Port	CD-STB 3	3
4	4 Port	VIDEO 4	4
5	5 Port	TAPE 5	5
6	6 Port	TUNER 6	6
7	7 Port	AUX-HDD 7	7
8	8 Port	USB 8	8
9	9 Port	BLUETOOTH 9	9

Original		Replacement	
+10 D.TUN DIMMER	+10 / Dimmer	GUIDE EPG	Guide / EPG / -/--
+10 D.TUN DIMMER	+10 / Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
0	0 Port	HDMI-SAT 0	0
CLR SLEEP	CLR / Sleep Port	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CLR SLEEP	CLR / Sleep Port	TIMER SLEEP	Sleep / Timer