Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
1..@	1	1	1
2ABC	2	2	2
3DEF	3	3	3
4GHI	4	4	4
5JKL	5	5	5
6MNO	6	6	6
7PQRS	7	7	7
8TUV	8	8	8
9WXYZ	9	9	9
0	0	0	0
PGUP	PgUp	+ CH	Ch +
PGDN	PgDn	CH -	Ch -
FAV+	FAV+	>>I	>>I
FAV-	FAV-	I<<	I<<
	Up/CH+		Up

Original		Replacement	
	Down/CH-		Down
VOL	Right		Right
VOL	Left		Left
OK	OK	OK	Ok
VOL	Vol+	+ VOL	Vol +
VOL	Vol-	VOL -	Vol -
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
EPG	Red	A	Red
AUDIO	Green	B	Green
SUB	Yellow	C	Yellow
ZOOM	Blue	D	Blue
EPG	EPG	GUIDE	Guide
AUDIO	Audio	SOUND DUAL	Dual
SUB	SUB	AD SUBT	Subt
ZOOM	Zoom	ZOOM	Eject
FAV	FAV	FAV PRE-CH	Pre Ch

Original		Replacement		Original		Replacement
LIST	List	DISC NAV LIST	List			
PAUSE	Pause	II	Pause			
TXT	TXT	REPEAT TEXT	Text			
INFO	Info	DISPLAY INFO	Info			
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R			
RECALL	Recall	RETURN BACK	Back			