Original	Replacement	Original	Replacement
Power	Power	Left	Left
Mute	Mute / Dimmer	OK	OK
Play	Play / Slow	Right	Right
Stop	Stop / Hold	Down	Down
Rec	Rec / Rec Mode	Vol +	Vol +
<<	<< / Tune-	[-O-] / Active Control	Smart / List
>>	>> / Tune+	P+	CH+ / Page+
(O	Audio / Lang I/II	Vol -	Vol -
[<>]	Picture / Format	P-	CH- / Page-
Green/Timer	Sleep / Timer	1	1
>I <	D.Menu / Top	2	2
[1I 2]	Setup / OPT /	3	3
[≡]	Text / Goto	4	4
Source	AV / Input / RDS	5	5
Menu	Menu / Home	6	6
Up	Up	7	7
[i +]	Info / Angle	8	8

Original	Replacement
9	9
Guide	Guide / EPG / -/--
0	0
P<P	Fav / Marker / PC
Red	Red / Netflix / Search
Green/Timer	Green / APP / Repeat
Yellow/[ ]	Yellow / YouTube / Repeat
Blue/[...]	Blue / Prime Video / Random
Power AMP	Shift + Power
Mute AMP	Shift + Mute / Dimmer
<< AMP	Shift + << /
>> AMP	Shift + >> /
[≡] AMP	Shift + Text /
Menu AMP	Shift + Menu /
Up AMP	Shift + Up
Left AMP	Shift + Left
OK AMP	Shift + OK

Original	Replacement
Right AMP	Shift + Right
Down AMP	Shift + Down
Vol + AMP	Shift + Vol +
P+ AMP	Shift + CH+ /
Vol - AMP	Shift + Vol -
P- AMP	Shift + CH- /
1 AMP	Shift + 1
2 AMP	Shift + 2
3 AMP	Shift + 3
4 AMP	Shift + 4
5 AMP	Shift + 5
6 AMP	Shift + 6
7 AMP	Shift + 7
8 AMP	Shift + 8
9 AMP	Shift + 9
Guide AMP	Shift + Guide / EPG / -/--
0 AMP	Shift + 0

Original	Replacement	Original	Replacement
P<P AMP	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC		

Original	Replacement	Original	Replacement
Power	Power	P+	CH+ / Page+
Source	AV / Input / RDS	Vol -	Vol -
>>	>> / Tune+	P-	CH- / Page-
<<	<< / Tune-	1	1
Stop	Stop / Hold	2	2
Play	Play / Slow	3	3
Guide	Guide / EPG / -/--	4	4
[≡]	Text / Goto	5	5
Up	Up	6	6
Left	Left	7	7
OK	OK	8	8
Right	Right	9	9
Down	Down	[i+]	Info / Angle
>I<	D. Menu / Top	0	0
Menu	Menu / Home	P<P	Fav / Marker / PC
Vol +	Vol +	[1l2]	Setup / OPT /
Mute	Mute / Dimmer	[-O-]/Active Control	Smart / List

Original	Replacement	Original	Replacement
[<>]	FORMAT PICTURE Picture / Format		

Original		Replacement		Original		Replacement	
	Power		Power		OK		OK
	Mute		Mute / Dimmer		Right		Right
	Play		Play / Slow		Down		Down
	Stop		Stop / Hold		Vol +		Vol +
	Rec		Rec / Rec Mode		[-O-] / Active Control		Smart / List
	<<		<< / Tune-		P+		CH+ / Page+
	>>		>> / Tune+		Vol -		Vol -
	(O		Audio / Lang I/II		P-		CH- / Page-
	[<>]		Picture / Format		1		1
	Green/Timer		Sleep / Timer		2		2
	>I<		D.Menu / Top		3		3
	[1I2]		Setup / OPT /		4		4
	Source		AV / Input / RDS		5		5
	Menu		Menu / Home		6		6
	Up		Up		7		7
	[i+]		Info / Angle		8		8
	Left		Left		9		9

Original	Replacement
0	0
P<P	Fav / Marker / PC
Red	Red / Netflix / Search
Green/Timer	Green / APP / Repeat
Yellow/[ ]	Yellow / YouTube / Repeat
Blue/[...]	Blue / Prime Video / Random
Power VCR	Shift + Power
Play VCR	Shift + Play /
Stop VCR	Shift + Stop /
Rec VCR	Shift + Rec / Rec Mode
<< VCR	Shift + << /
>> VCR	Shift + >> /
>I < VCR	Shift + D. Menu / Top Menu
Source VCR	Shift + AV / Input / RDS
Menu VCR	Shift + Menu /
Up VCR	Shift + Up
[i+] VCR	Shift + Info / Angle

Original	Replacement
Left VCR	Shift + Left
OK VCR	Shift + OK
Right VCR	Shift + Right
Down VCR	Shift + Down
P+ VCR	Shift + CH+ /
P- VCR	Shift + CH- /
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9
0 VCR	Shift + 0
P<P VCR	Shift + Fav / Marker / PC

Original	Replacement	Original	Replacement
Power	Power	2	2
>>	>> / Tune+	3	3
<<	<< / Tune-	4	4
Stop	Stop / Hold	5	5
Play	Play / Slow	6	6
Guide	Guide / EPG / -/--	7	7
Up	Up	8	8
Left	Left	9	9
Right	Right	[i+]	Info / Angle
Down	Down	0	0
>I<	D.Menu / Top	P<P	Fav / Marker / PC
Vol +	Vol +		
Mute	Mute / Dimmer		
P+	CH+ / Page+		
Vol -	Vol -		
P-	CH- / Page-		
1	1		