Mandis shop

RB-MCR350MO

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
⏻/ON	Standby/On		Power
FUNCTION	Function	OPT-TOOLS SETUP	Setup / OPT /
MEMORY	Memory	LIST SMART	Smart / List
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PRESET FOLDER SELECT	Preset/Folder Select	OK	OK
0	0	HDMI-SAT 0	0
OVER	Over	PC FAV MARKER	Fav / Marker / PC

Original		Replacement	
VOL −	Vol -	VOL −	Vol -
⏯	Play	SLOW ▶	Play / Slow
⏯	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
SOUND	Sound	TITLE SOUND	Sound / Title
VOL +	Vol +	+ VOL	Vol +
■	Stop	HOLD ■	Stop / Hold
−TUNING/ ⏮	I<</Tuning/File-	PRESET- ⏮	I<< / Preset-
TUNING/FILE+ ⏭	Tuning/File+/>>I	PRESET+ ⏭	>>I / Preset+
DISPLAY	Display	MEDIA DISPLAY	Display / Media
CD RANDOM	CD Random	SHIFT + CD-STB 3	Shift + 3
TAPE ▶	Tape >	SHIFT + TAPE 5	Shift + 5
FM MODE/ REPEAT	FM	PROGRAM TV/RADIO	TV/Radio /
◀◀	<< Tape	TUNE- ◀◀	<< / Tune-
▶▶	Tape >>	TUNE+ ▶▶	>> / Tune+
■	Stop Tape	SHIFT + HOLD ■	Shift + Stop /
●	Rec Tape	SHIFT + REC MODE ●	Shift + Rec / Rec Mode
●/II	Rec/Pause Tape	REC MODE ●	Rec / Rec Mode

https://al-remotecontrols.co.uk/p/1338-708-replacement-remote-control-for-RB-MCR350MO-65674.htm