Original		Replacement	
	Standby TV		Power
	Tv/Video TV	SEARCH TV/R	TV/R
	CH+ TV	CH +	Ch +
	CH- TV	CH –	Ch -
	Vol + TV	VOL +	Vol +
	Vol - TV	VOL –	Vol -
1	1 TV	1	1
2	2 TV	2	2
3	3 TV	3	3
4	4 TV	4	4
5	5 TV	5	5
6	6 TV	6	6
7	7 TV	7	7
8	8 TV	8	8
9	9 TV	9	9
0/10	0/10 TV	0	0
>10 CLEAR	-/-- TV	-/-- GUIDE	Guide

Original		Replacement	
MEMORY D.SKIP	Enter/Memory/D.Skip TV	FAV PRE-CH	Pre Ch
AV I/⏻	Standby AV Video	SHIFT + ⏻	Shift + Power
VIDEO 1	Video 1	A	Red
VIDEO 2	Video 2	B	Green
SA-CD/CD	SA-CD/CD	C	Yellow
DVD	DVD	D	Blue
TUNER	Tuner	APP MEDIA	Media
SLEEP	Sleep	PROG SLEEP	Sleep
TEST TONE	Test Tone	HOME SMART	Smart
2CH	2CH	REPEAT TEXT	Text
A.F.D.	A.F.D.	SETTINGS OPT	Options
MOVIE	Movie	PICTURE FORMAT	Format
MUSIC	Music	SOUND DUAL	Dual
DUAL MONO	Dual Mono	ECO 3D	3D
MAIN MENU	Main Menu	TOP MENU MENU	Menu
FM MODE MPX AUDIO	MPX/FM Mode/Audio Video	SHIFT + SEARCH TV/R	Shift + TV/R
D.TUNING SUBTITLE	ANT/D.Tuning/Subtitle Video 1	AD SUBT	Subt

Original		Replacement	
Enter/Memory/D.Skip Video 1		SHIFT +	Shift + Pre Ch
1 Video 1		SHIFT + 1	Shift + 1
2 Video 1		SHIFT + 2	Shift + 2
3 Video 1		SHIFT + 3	Shift + 3
4 Video 1		SHIFT + 4	Shift + 4
5 Video 1		SHIFT + 5	Shift + 5
6 Video 1		SHIFT + 6	Shift + 6
7 Video 1		SHIFT + 7	Shift + 7
8 Video 1		SHIFT + 8	Shift + 8
9 Video 1		SHIFT + 9	Shift + 9
0/10 Video 1		SHIFT + 0	Shift + 0
-/--/>10/Clear Video 1		SHIFT + GUIDE	Shift + Guide
AV Menu Video		TIMER AV	AV
Up Video 1			Up
Down Video 1			Down
Right Video 1			Right
Left Video 1			Left

Original		Replacement	
Enter Video 1	ENTER	OK	Ok
Display Video	DISPLAY	DISPLAY INFO	Info
Master Vol +	TV VOL MASTER VOL +	SHIFT + VOL +	Shift + Vol +
Master Vol -		SHIFT + VOL –	Shift + Vol -
Muting	MUTING	MUTE	Mute
Play Video 1		PLAY MODE ▶	Play
Pause Video 1		⏸	Pause
Stop Video 1		■	Stop
<</Tuning- Video	TUNING –	≪	≪
>>/Tuning+	TUNING +	≫	≫
I<</Preset+	TV CH – PRESET –	I≪	I≪
>>I/Preset + Video 1	TV CH + PRESET +	≫I	≫I
·→Advance/Step I> Video 1	STEP ADVANCE	SHIFT + CH +	Shift + Ch +
←/Replay/<I Step Video 1	REPLAY	SHIFT + CH –	Shift + Ch -

Original	Replacement
Standby System	Power
Standby AV	Shift + Power
Sleep	Sleep
Test Tone	Smart
Play	Play
>>/ Tuning+	>>
<</ Tuning-	<<
Pause	Pause
Stop	Stop
Main Menu	Menu
Video 1	Red
Video 2	Green
SA-CD/CD	Yellow
DVD	Blue
Tuner	Media
1	1
2	2

Original	Replacement
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0/10	0
-/--/>10/Clear	Guide
Enter/Memory/D.S	Pre Ch
Top	Shift + Menu
AV Menu	AV
Muting	Mute
Return/Exit	Back
Display	Info
Master Vol +	Vol +
Master Vol -	Vol -

Original		Replacement		Original		Replacement	
PRESET –	I <</ Preset-	K<	I <<				
PRESET +	>>I / Preset+	>>I	>>I				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
ENTER	Enter	OK	Ok				
ADVANCE	· →Advance/ Step I >	+ CH	Ch +				
REPLAY	← / Replay/ <I Step	CH –	Ch -				
MUSIC	Music	SOUND DUAL	Dual				
MOVIE	Movie	PICTURE FORMAT	Format				
A.F.D.	A. F. D.	SETTINGS OPT	Options				
DUAL MONO	Dual Mono	ECO 3D	3D				
2CH	2CH	REPEAT TEXT	Text				
FM MODE MPX AUDIO	MPX/ FM	SEARCH TV/R	TV/ R				
D.TUNING SUBTITLE	ANT/ D. Tuning/ Subtitle	AD SUBT	Subt				
SHIFT ANGLE	Jump/ Shift/ Angle	DISC NAV LIST	List				

Original		Replacement	
Standby System		Power	
Standby AV		Shift + Power	
Sleep		Sleep	
Test Tone		Smart	
Video 1		Red	
Video 2		Green	
SA-CD/CD		Yellow	
DVD		Blue	
Tuner		Media	
Main Menu		Menu	
Music		Dual	
Movie		Format	
2CH		Text	
Dual Mono		3D	
A.F.D.		Options	
Enter/Memory/D.S		Pre Ch	
1		1	

Original		Replacement	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0/10		0	
-/--/>10/Clear		Guide	
Master Vol +		Vol +	
Master Vol -		Vol -	
Muting		Mute	
Display		Info	
Enter		Ok	
Play		Play	
Pause		Pause	

Original		Replacement		Original		Replacement
	Stop		Stop			
TUNING –	<</ Tuning-		<<			
TUNING +	>>/ Tuning+		>>			
PRESET –	I <</ Preset-		I <<			
PRESET +	>>I / Preset+		>>I			

Original		Replacement	
VIDEO 1	Video 1	A	Red
VIDEO 2	Video 2	B	Green
SA-CD/CD	SA-CD/CD	C	Yellow
DVD	DVD	D	Blue
TUNER	Tuner	HOME SMART	Smart
TV/VIDEO SLEEP	Sleep	PROG SLEEP	Sleep
TV I/⏻	Standby System	⏻	Power
MAIN MENU	Main Menu	TOP MENU MENU	Menu
2CH	2CH	REPEAT TEXT	Text
A.F.D.	A. F. D.	SETTINGS OPT	Options
MOVIE	Movie	PICTURE FORMAT	Format
MUSIC	Music	SOUND DUAL	Dual
DUAL MONO	Dual Mono	ECO 3D	3D
FM MODE MPX AUDIO	MPX/FM Mode/Audio Tuner	SEARCH TV/R	TV/R
D.TUNING SUBTITLE	ANT/D. Tuning/Subtitle Tuner	AD SUBT	Subt
SHIFT ANGLE	Jump/Shift/Angle Tuner	DISC NAV LIST	List
1	1 Tuner	1	1

Original		Replacement	
2	2 Tuner	2	2
3	3 Tuner	3	3
4	4 Tuner	4	4
5	5 Tuner	5	5
6	6 Tuner	6	6
7	7 Tuner	7	7
8	8 Tuner	8	8
9	9 Tuner	9	9
0/10	0/10 Tuner	0	0
MEMORY D.SKIP	Enter/Memory/D.Skip Tuner	FAV PRE-CH	Pre Ch
MUTING	Muting	MUTE	Mute
TV VOL MASTER VOL +	Master Vol +	+ VOL	Vol +
MASTER VOL −	Master Vol -	VOL −	Vol -
DISPLAY	Display Tuner	DISPLAY INFO	Info
TV CH − PRESET −	I<</Preset- Tune	⏮	I<<
TV CH + PRESET +	>>I/Preset+	⏭	>>I
TUNING −	<</Tuning- Tuner	⏪	<<

Original		Replacement	
TUNING +	>>/ Tuning+	>>	>>
TEST TONE	Test Tone	APP MEDIA	Media
Standby Video		SHIFT +	Shift + Power
FM MODE MPX AUDIO	MPX/ FM Mode/ Audio Video	SHIFT +	SEARCH TV/R Shift + TV/ R
D.TUNING SUBTITLE	ANT/ D. Tuning/ Subtitle Video 2	SHIFT +	AD SUBT Shift + Subt
MEMORY D.SKIP	Enter/ Memory/ D. Skip Video 2	SHIFT +	FAV PRE-CH Shift + Pre Ch
1	1 Video 2	SHIFT + 1	Shift + 1
2	2 Video 2	SHIFT + 2	Shift + 2
3	3 Video 2	SHIFT + 3	Shift + 3
4	4 Video 2	SHIFT + 4	Shift + 4
5	5 Video 2	SHIFT + 5	Shift + 5
6	6 Video 2	SHIFT + 6	Shift + 6
7	7 Video 2	SHIFT + 7	Shift + 7
8	8 Video 2	SHIFT + 8	Shift + 8
9	9 Video 2	SHIFT + 9	Shift + 9
0/10	0/10 Video 2	SHIFT + 0	Shift + 0
>10 CLEAR	-/ - - / >10/ Clear Video 2	-/ -- GUIDE	Guide

Original		Replacement	
AV BACKGROUND	AV Menu Video	TIMER AV	AV
	Up Video 2		Up
	Down Video 2		Down
	Right Video 2		Right
	Left Video 2		Left
ENTER	Enter Video 2	OK	Ok
DISPLAY	Display Video	SHIFT + DISPLAY INFO	Shift + Info
	Play Video 2	PLAY MODE	Play
	Pause Video 2		Pause
	Stop Video 2		Stop
REPLAY	←/ Replay/ ◁ I Step Video 2	CH -	Ch -
ADVANCE	·→Advance/ Step I > Video 2	CH +	Ch +
TV CH + PRESET +	>>I / Preset +	SHIFT +	Shift + >>I
TV CH - PRESET -	I <</ Preset - Vide	SHIFT +	Shift + I <<
TUNING +	>>/ Tuning+	SHIFT +	Shift + >>
TUNING -	<</ Tuning- Video	SHIFT +	Shift + <<