Original		Replacement	
	Power		Power
PROGRAM	Program	PROGRAM TV/ RADIO	TV/ Radio /
OPEN/CLOSE	Open/ Close	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
PLAY/PAUSE	Play	SLOW	Play / Slow
C	C	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SKIP/F	I<< Skip/ Frame	PRESET-	I<< / Preset-

Original		Replacement	
SLOW/SE	<< Slow/ Search	TUNE-	<< / Tune-
/SEARCH	Slow/ Search >>	TUNE+	>> / Tune+
/FRAME	Skip/ Frame >>I	PRESET+	>>I / Preset+
PLAY/PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
TITLE	Title	TITLE SOUND	Sound / Title
MENU	Menu	HOME MENU	Menu / Home
DISPLAY	Display	MEDIA DISPLAY	Display / Media
SEARCH MODE	Search Mode	NETFLIX SEARCH	Red / Netflix / Search
	Up		Up
	Down		Down
	Right		Right
	Left		Left
SELECT	Select	OK	OK
RETURN	Return	RETURN BACK	Back / Return
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ

Original	Replacement	Original	Replacement
AUDIO Audio	LANG I/II AUDIO Audio / Lang I/II		
ANGLE Angle	ANGLE INFO Info / Angle		
TIME Time	TIMER SLEEP Sleep / Timer		
REPEAT Repeat	APP REPEAT Green / APP / Repeat		
A→B A–B	YouTube REPEAT A-B Yellow / YouTube / Repeat		