Mandis shop

Sony RM-PJ7

Original		Replacement	
I/⏻	Standby	ON	On
INPUT	Input	SEARCH SRC	SRC / Search
APA	Apa	OFF	OFF
ECO MODE	Eco Mode	MODE AUTO	Auto / Mode
MENU	Menu	MENU/INFO	Menu / Info
RESET	Reset	-- USB	-- / USB
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ENTER	Enter	OK	OK
RETURN	Return	EXIT/LAMP	Exit / Lamp
ASPECT	Aspect	ASPECT/RE	Aspect / Re-Sync
KEYSTONE	Keystone	BLANK HIDE	Hide / Blank
PATTERN	Pattern	K.S.	K.S. / PIP
PIC MUTING	PIC Muting	0 LAN	0 / Lan
AUDIO MUTING	Audio Muting	FOCUS	Mute / Focus

Original		Replacement	
FREEZE	Freeze	/FREEZE	Pict / Freeze
+ VOLUME	Volume+	+ VOL PAGE	Vol +
VOLUME −	Volume-	VOL PAGE −	Vol -
+ D ZOOM	D.Zoom+	K.S. ZOOM	KS Up
D ZOOM −	D.Zoom-	K.S. ZOOM	KS Down

https://all-remote-controls.co.uk/en/Sony/1021616-66145-replacement-remote-control-for-Sony-RM-PJ7-148922211.html