Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
LANG.	Lang	LANG I/II AUDIO	Audio / Lang I/II
	Source (Games)	SURROUND	Eject / Surround
	Movie-Music-Phot	FORMAT PICTURE	Picture / Format
	[≡] . .	SIZE ZOOM	Zoom / Size
	*/O	TIMER SLEEP	Sleep / Timer
	TV	PROGRAM TV/RADIO	TV/Radio /
Q. MENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top
	[- O-]	OPT-TOOLS SETUP	Setup / OPT /
	[≡] / Text	GOTO TEXT	Text / Goto

Original		Replacement	
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
i	i	ANGLE INFO	Info / Angle
	Left		Left
OK	OK	OK	OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
BACK	Back	RETURN BACK	Back / Return
V	Vol +	VOL	Vol +
	World (Violet)	LIST SMART	Smart / List
P	PR+	CH PAGE	CH+ / Page+
V	Vol -	VOL	Vol -
	*/Q	MEDIA DISPLAY	Display / Media
P	PR-	CH PAGE	CH- / Page-
1	1	TV 1	1
2 abc	2	DVD 2	2

Original		Replacement		Original	Replacement
3 def	3	CD - STB 3	3		
4 ghi	4	VIDEO 4	4		
5 jkl	5	TAPE 5	5		
6 mno	6	TUNER 6	6		
7 pqrs	7	AUX - HDD 7	7		
8 tuv	8	USB 8	8		
9 wxyz	9	BLUETOOTH 9	9		
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
	Recall	SHIFT + RETURN BACK	Shift + Back / Return		