Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
AUDIO	Audio	SOUND DUAL	Dual
SUB-T	Sub-T	AD SUBT	Subt
INFO	Info	DISPLAY INFO	Info
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
PGUP	PgUp	+ CH	Ch +

Original		Replacement	
PGDN	PgDn	CH –	Ch -
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
II/▶	Play	PLAY MODE ▶	Play
II/▶	Pause/Timeshift	II	Pause
◀◀	<<	≪	<<
▶▶	>>	≫	>>
I◀◀	I<<	I≪	I<<
▶▶I	>>I	≫I	>>I
OK	OK	OK	Ok
CH+	Up/CH+	▲	Up
CH-	Down/CH-	▼	Down
VOL +	Vol+	+ VOL	Vol +
VOL +	Right	▶	Right
VOL -	Left	◀	Left
VOL -	Vol-	VOL –	Vol -
GOTO	Goto	RETURN BACK	Back

Original		Replacement	
REC	Rec	REC MODE	Rec
■	Stop	■	Stop
SLIDE SHOW	Slide Show	TIMER AV	AV
DVB-T	DVB-T	HOME SMART	Smart
EPG	EPG	-/-- GUIDE	Guide
TTX	TTX	REPEAT TEXT	Text
FAV	FAV	FAV PRE-CH	Pre Ch
SETUP	Setup	SETTINGS OPT	Options
REPEAT	Repeat	SHIFT + REPEAT TEXT	Shift + Text
TV SYSTEM	TV System	PICTURE FORMAT	Format
ZOOM	Zoom	ZOOM ⏏	Eject
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue

Original	Replacement