Mandis shop

Sony RMT-811

Original	Replacement
Start/Stop	Power
T	Up
W	Down
Photo	Media
Zero Set	Menu
Display	Info
Data Code	Smart
Play Memory	Ok
Index Memory	Guide
Memory-	Ch -
Memory+	Ch +
Search Mode	AV
I<<	I<<
>>I	>>I
<<	<<
Play	Play
>>	>>

Original	Replacement
<II/<	Left
Stop	Stop
>/II>	Right
Pause	Pause
Slow I>	Shift + >>
x2	Options
Rec	Rec
Mark	3D
Audio Dub	Dual

https://all-remote-controls.co.uk/en/Sony/1039550-9224-replacement-remote-control-for-Sony-RMT-811-147595042.html