Mandis shop

Sharp RRMCG0047SJSA

Original		Replacement	
G1	CD 1	1	1
G2	CD 2	2	2
G3	CD 3	3	3
MEMORY /SET	Memory Set	MENU	MENU
CD II	Pause CD	II	Pause
■	Stop	■	Stop
▶	Play/Back	▶	Play
CLEAR	Clear	EXIT	EXIT
RANDOM	Random	MEDIA	MEDIA
⏮	I<<</Preset	⏮	First
⏭	>>I/Preset Up	⏭	Last
EQUALIZER MODE	Equalizer Mode	....	Subt.
CLOCK	Clock	FAV 2. P/C	P/C / FAV
TIMER	Timer	EPG 1. -/--	-/-- / EPG
SLEEP	Sleep	VOD	VOD
CD	CD	C	Yellow (C)
TUNER (BAND)	Tuner/Band	A	Red (A)

Original		Replacement	
TAPE	Tape	B	Green (B)
ON/ STAND-BY	On/Standby	⏻	Power
X-BASS	X-Bass	🔊?	Audio
VOL ▽	Vol -	VOL −	VOL -
VOLUME △	Vol +	+ VOL	VOL +

https://al-remotecontrols.co.uk/Sharp/1357-251-replacement-remote-control-for-Sharp-RRMCG0047SJSA.htm