Mandis shop

# Panasonic N2QAYB000432

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| ASPECT | Aspect | ECO 3D | 3D |
| OFF TIMER | Off Timer | PROG SLEEP | Sleep |
| AUTO SETUP | Auto Setup | HOME SMART | Smart |
| POS./SIZE | Pos./Size | AD SUBT | Subt |
| PICTURE | [ ]/Picture | PICTURE FORMAT | Format |
| SOUND | ♪/Sound | SOUND DUAL | Dual |
| SET UP | Set Up | TOP MENU MENU | Menu |
| MUTE | Mute | MUTE | Mute |
| VOL + | Vol+ | + VOL | Vol + |
| VOL − | Vol- | VOL − | Vol - |
| N | N | SETTINGS OPT | Options |
| R | R | REPEAT TEXT | Text |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |

| Original | | Replacement | |
|---|---|---|---|
| | OK | OK | Ok |
| INPUT | Input | TIMER AV | AV |
| RECALL | [ +]/Recall | RETURN BACK | Back |
| MULTI PIP | Multi PIP | APP MEDIA | Media |
| SWAP | Swap | FAV PRE-CH | Pre Ch |
| SELECT | Select | -/-- GUIDE | Guide |
| MOVE ZOOM | Move/Zoom | ZOOM | Eject |

https://all-remote-controls.co.uk/en/Panasonic/1055110-84945-replacement-remote-control-for-Panasonic-N2QAYB000432.html