Original		Replacement	
POWER	Power		Power
TV/AV	Tv/ AV	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	- / - -	SHIFT + -/-- GUIDE	Shi f t + Gui de
EJECT	Ej ect	ZOOM	Ej ect
PLAY/PAUSE	Pl ay/ Pause	PLAY MODE	Pl ay
STOP	St op		St op
RETURN	Ret ur n	RETURN BACK	Back

Original		Replacement	
MUTE	Mut e	MUTE	Mut e
VOL +	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
CH+	Up		Up
CH+	CH+	+ CH	Ch +
CH–	CH-	CH –	Ch -
CH–	Down		Down
	Ri ght		Ri ght
	Lef t		Lef t
SYS MENU	Sys Menu	TOP MENU MENU	Menu
DISPLAY	Di spl ay	SHIFT + DISPLAY INFO	Shi f t + I nf o
OK	OK	OK	Ok
PICTURE	Pi ct ur e	PICTURE FORMAT	For mat
SOUND	Sound	SOUND DUAL	Dual
TIMER	Ti mer	SHIFT + TIMER AV	Shi f t + AV
NICAM/A2	Ni cam/ A2	APP MEDIA	Medi a
PROG – LAN	Lan/ Pr og-	SHIFT + CH –	Shi f t + Ch -

Original	Replacement	Original	Replacement
PROG+ ZOOM Zoom/ Prog+	SHIFT + CH + Shift + Ch +	SUBTITLE A-B Blue/ A-B/ Subtitl	D Blue
SUB Sub	AD SUBT Subt		
GOTO Goto	SETTINGS OPT Options		
TV/TXT DVB-MENU SET SET/ Tv/ TXT/ DVB-	REPEAT TEXT Text		
REVEAL EXIT ANG ANG/ Reveal / Exit	CLEAR EXIT Exit		
CANCEL TV FORMAT MENU Menu/ Cancel / Tv Format	E-MANUAL D.MENU D. Menu		
INFO TITLE Title/ info	DISPLAY INFO Info		
HOLD LANGUAGE << << / Hold/ Languag	<< <<		
SIZE TEXT >> >> / Size/ Text	>> >>		
SUBPAGE FAV I << << / Subpage	I << I <<		
SUBPAGE FAV FAV	FAV PRE-CH Pre Ch		
INDEX EPG >>I >>I / Index	>>I >>I		
INDEX EPG EPG	-/-- GUIDE Guide		
TV/RADIO PRO Red/ Pro	A Red		
TV/RADIO PRO Tv/ Radio	SEARCH TV/R TV/R		
AUDIO SLOW Green/ Slow/ Audio	B Green		
FREEZE REP Yellow/ Rep/ Freeze	C Yellow		